

NEC

SV8100 Mobile Extension

User Guide



OPERATION

With any feature, if the Mobile Extension user presses *, an existing call is placed on hold.

Pressing * a second time or the timeout of the inter-digit timer returns the call to conversation mode.

USING ANALOG LINES WITH MOBILE EXTENSION

Analog lines can be used for integration with the Mobile Extension using DILs to access the Mobile Extension Proxy Port. However, it must be noted that the *0 Hang Up code must be used prior to terminating any call (e.g., transfer, hang up etc.) as analog trunks do not provide Disconnect Supervision.

PLACING AN INTERCOM CALL TO A MOBILE EXTENSION

- Lift the handset or press the **Speaker** key
- Dial the extension number assigned to the Mobile Extension
- If the Mobile Extension is turned off, incoming callers hear a message indicating the user is not available.

OUTSIDE PARTY DIALING THE MOBILE EXTENSION

- Dial the DID or DIL telephone number for the Mobile Extension
- If the Mobile Extension is turned off, incoming callers hear a message indicating the user is not available.

PLACING A CALL FROM THE MOBILE EXTENSION

- Dial the main office number or DID for the Mobile Extension
- If the Caller ID of the Mobile Extension matches the Speed Dial bin entry, internal dial tone is heard by the Mobile Extension user
- Dial the desired Intercom number or dial the trunk access code (usually "9") to place an outgoing call

ANSWERING A CALL ON THE MOBILE EXTENSION

- Answer the ringing call
- The Mobile Extension user hears the second dial tone
- Press * within 10 seconds to answer the call
- This step is required when using analog trunks for the Mobile Extension feature.

SENDING A FLASH FROM THE MOBILE EXTENSION

- During a conversation, a hook flash is returned by dialling *# from the Mobile Extension

INTERNAL DIAL TONE AFTER HANG UP

- When a call is finished, disconnect the call and receive internal dial tone by dialling *0

PLACING/RETRIEVING A CALL ON HOLD FROM THE MOBILE EXTENSION

- While on a call, press * #
- To retrieve the held call, with system dial tone, press * #

SWAPPING BETWEEN TWO HELD CALLS FROM THE MOBILE EXTENSION

- While on a call, press * #
- The first call is placed on Hold
- Place second call, then place on Hold by pressing * #
- The second call is placed on Hold and the first call is picked up
- The Mobile Extension can connect the two held calls with Automatic On-Hook Transfer by dialling * 0.

TRANSFERRING A CALL FROM THE MOBILE EXTENSION

- During an active call, press * #
- Dial the extension number to which the call is to be transferred
- Dial * 0
- Hang up

CALL FORWARDING

When activating Call Forwarding to the Mobile Extension:

- Press **Speaker** or lift the handset
- Dial 741
- Dial Call Forwarding instruction:
 - 1 = Set
 - 0 = Cancel
- Dial the mobile extension
- Hang up

When cancelling Call Forwarding to the Mobile Extension:

- Press **Speaker** or lift the handset
- Dial 741
- Dial **0**
- Dial mobile extension or Dial 0 to cancel all
- Hang up

NEC

NEC Unified Solutions, Inc.
6555 N. State Hwy. 161
Irving, TX 75039
TEL: 214-262-2000
www.necunifiedsolutions.com